

1. Disconnect the USB cable for the PC.
2. Go to Start/Programs or All Programs depending how you have Windows setup.
3. Select ULS Engraver and then Uninstall.
4. Reboot you PC, this mandatory.
5. Double click on the .exe and install the driver.
6. Reboot your PC again, this is mandatory.
7. Connect the USB cable.