

### **Testing Air Flow**

1. Open Run Ultr@VNC Viewer.
2. Type password (ulsl).
3. Press the letter Q on keyboard. Doing so will stop power to fans and laser tube on the engraver.
4. Press start (Window Flag) in VNC.
5. From Admin window choose ULS folder.
6. Scroll down to Airhost.exe and double click.
7. The window allowing you to manually test air will open. Set flow for 10 to 1000.