

Driver Mismatch

Mismatch error, display mismatch from PC to system (dual head, driver mismatch).

Go to Preferences / About. Press NEXT FILE and START at the same time. Each time you press next file and start the display will scroll to the next model. Stop when your model appears. Power system down.