

Job Parameter Menu

Color: Black, Red, Green, Yellow, Blue, Magenta, Cyan, Orange. The display will show parameter settings for chosen color.

Mode: Rast / Vect, Rast, Vect, Skip. Any of the modes can be forced.

Power: 0 to 100%, power can be adjusted on the fly.

Speed: 0.1 to 100%, speed can be adjusted on the fly.

PPI: Pulse per inch, PPI can't be changed after file has started marking.

Z Axis: On / Off, allows Auto Z to be programmed for desired color.

Air / Gas Valve: Off / Air / Gas.

Air / Gas Flow: Adjustable from 20 to 100%.

Image Density: Lines per inch, adjustable only at print driver.

Which Laser: Both/ Top / Bottom

Red Dot Pointer: On / Off

Delete This File: Yes / No, used to delete selected file.