











### Cutting Table (Optional)

Installed Yes / No: Used for calibration of an optional cutting table.

1. Home Z axis.
2. Press  to enter the motion menu.
3. Press  again until Z axis is highlighted.
4. Press  to accept.
5. SYSTEMS OPTIONS MENU will appear.
6. Scroll down to the CUTTING TABLE INSTALLED.
7. Press  to enter.
8. Press  again to toggle CUTTING TABLE INSTALLED.
9. Press  to accept.
10. Press the DOWN SCROLL ARROW  too choose CALIBRATE.
11. Press  to open CALIBRATE MENU, using the focus tool, focus to the top of the cutting table by pressing either the up or down arrow .
12. Press , you will be prompted to save new Z position, choose yes or no.
13. You have now completed focus to the CUTTING TABLE.